

RULES

- ◆ Never jump or play on partially inflated unit
 - ◆ Do not allow riders to play or climb on outside walls, sides, or roof of unit
 - ◆ Suggested number for standard unit is 8; please use your own judgment for age, height and weight of riders.
 - ◆ Riders must remove shoes, eyeglasses and other sharp objects before entering unit
 - ◆ Do not plug and unplug motor repeatedly as it will cause it to burn up
 - ◆ Never put a hose or water on unit
 - ◆ In case of rain, remove riders and unplug motor and extension cord from wall outlet, cover unit. Do not let water remain in unit.
 - ◆ Always have an adult present to supervise riders
 - ◆ Do not allow flips, horseplay, wrestling or roughhousing on unit
 - ◆ Do not allow riders to hang on or pull netting or columns
 - ◆ Follow all rules posted on unit and blower
 - ◆ Do not use silly string in unit
-

TROUBLE SHOOTING

If the unit is soft, check the following:

- ◆ Are all blower necks and air release stubs tied off
- ◆ Blower neck must be straight with no bends or kinks
- ◆ Blower should be the only thing plugged into the circuit

Is blower not working? Check the following:

- ◆ Is blower plugged into extension cord?
- ◆ Is extension cord plugged into receptacle?
- ◆ Check receptacle with small electric device such as lamp or dryer. If not working check fuses/circuit breaker